

100

1. Latin Toys

Note No.		
C-1	0	Bass Gliss
	1	GuitarScrth
	2	WahGt1 Down
	3	WahGt1 Up
	4	WahGt2 Down
	5	WahGt2 Up
	6	CR78Guiro
	7	CR78Tamb
	8	TR808Clap
	9	TR808Cowbell
C0	10	TR808Maracas
	11	TR909Clap
	12	Hi-Q
	13	R8Slap
	14	Scratch2
	15	Scratch3
	16	Sticks
	17	Click
	18	MetroClick
	19	MetroBell
C1	20	Clap
	21	VibraSlap
	22	SquareBlock
	23	Off
	24	Beep
	25	Crotale
	26	SquareBlock
	27	6"SplazhSpEg
	28	6"SplazhSpBw
	29	Guiro Short
C2	30	Guiro Long
	31	Cuica Hi
	32	Cuica Lo
	33	Cowbell Hi
	34	Cowbell Lo
	35	Cowbell Lo
	36	Cowbell Mute
	37	Tambourine1
	38	Tambourine2
	39	Conga LoMute
C3	40	Tambourine1
	41	Conga Lo
	42	Claves
	43	Conga Hi
	44	Claves
	45	Bongo Lo
	46	Claves
	47	Bongo LoSlap
	48	Bongo Hi
	49	Triangle
C4	50	Bongo HiSlap
	51	SleighBell
	52	Agogo Lo
	53	BellTree
	54	Tambourine1
	55	TriangleCls
	56	Cowbell Mute
	57	Agogo Hi
	58	Conga HiSlap
	59	TreeChimes

Drum Kit 1–50 (Trigger Inputs)

Drum	Frequency (Hz)
65	66
67	68
69	70
71	
C5	72
74	73
76	75
77	78
79	80
81	82
83	
C6	84
86	85
88	87
89	90
91	92
93	94
95	
C7	96
98	97
100	99
101	
103	102
105	104
107	106
C8	108
110	109
112	111
113	
115	114
117	116
119	118
C9	120
122	121
124	123
125	
127	126

Note No.		
C4	60	Bongo Hi
	61	Bongo Lo
	62	Conga Hi
	63	Conga HiSlap
	64	Conga Lo
	65	Timbale Hi
	66	Timbale Lo
	67	Agogo Hi
	68	Agogo Lo
	69	Cabasa
C5	70	Maracas
	71	WhistleShort
	72	Whistle
	73	Guiro Short
	74	Guiro Long
	75	Claves
	76	Block Hi
	77	Block Lo
	78	Cuica Hi
	79	Cuica Lo
C6	80	TriangleCls
	81	Triangle
	82	Shaker
	83	SleighBell
	84	BellTree
	85	Castanet
	86	Surdo LoMute
	87	Surdo Lo
	88	Bongo HiSlap
	89	Bongo LoSlap
C7	90	Conga HiMute
	91	Conga LoMute
	92	PandeiroMute
	93	Pandeiro
	94	PandeiroSlap
	95	TreeChimes
	96	Crotale
	97	Gong
	98	Cajon Bass
	99	Cajon Mute
C8	100	Cajon Slap
	101	CowbellMambo
	102	SquareBlock
	103	Caxixi
	104	Timbale HiRm
	105	TimbalePaila
	106	Cuica Acc
	107	Surdo Hi
	108	Surdo HiMute
	109	PotDrum
C9	110	PotDrum Acc
	111	PotDrum Mute
	112	Djembe Tone
	113	Djembe Slap
	114	Djembe Bass
	115	TalkingDr
	116	TalkingDr Up
	117	Tabla Na
	118	Tabla Te
	119	Tabla Ti
C9	120	Tabla Tun
	121	Baya Ge
	122	Baya Gin
	123	Baya Ka
	124	Baya Slide
125	ConcertBD	
126	HandCymbal	
127	Off	

- Up to eight percussion sets can be stored.
- You can change the used instruments in each percussion set.
For details, refer to "Percussion Set Settings" (p. 73).